

3698 Assembly Instructions

Step 1 – Locate casters and the hardware.

Step 2 – Place all 4 casters through the holes in any of the provided shelves.

Step 3 – Thread the 4 long poles into the casters to lock the bottom shelf into place.

Step 4 – Thread on the 4 headless screws into the 4 medium poles until snug.

Step 5 – Lay another shelf on top of the 4 long poles.

Step 6 – Thread the 4 medium poles with headless screw down, through the second shelf. Twisting the medium poles will tighten both ends of the joint.

*Pro-Tip: Do not overtighten these poles, wait until after threading the 4 top allen-screws into place. Then Tighten the medium poles, and finally tighten the allen-screws.

Step 7 – Lay the final shelf on top of the medium poles.

Step 8 – Use the provided Allen Wrench to thread the 4 screws through the top shelf into the tops of the medium poles.

Things to note:

- All shelves have the same holes drilled.
- Casters have a “lock” feature. To transport, ensure locks are off.

